




Using the Studio Flash

This handout will list the parts of the Studio Flash unit and what it does.



A. Power Switch: Turns the unit on or off.

B. Range Switch: HI setting gives the brightest settings. LO setting give the least amount of light.

C. Light Dimmer Knob: Controls how bright the light will be.

D. Model Switch: Controls the settings for the Modeling light. Full will have the brightest light no matter what the Range or Light Dimmer are set to. Off causes the Modeling light to be turned off. Track causes the Modeling light to change as the Range or Light Dimmer are changed.

E. Test Button: This button will fire the flash unit. Do not look directly at the light as it could cause eye damage.

F. Slave Switch: Sets the unit to be either a "Master" (off setting) or "Slave" (on setting). When it is set to "Slave" the flash unit will fire when another flash fires, thus the effect of both flashes going off at the same time. The "Main" flash unit should be always set to "Master". The "Hair" light or "Background" light should be set to "Slave".